

EASY-LASER®

E540

English
MANUAL

05-0584 Revision 4.5
System version 12.6

CONTENT

INTRODUCTION	1	CHOOSE PROGRAM	23
Service and calibration	2	Preparations	23
Travelling with your measurement system	3	PROGRAM VALUES	25
DISPLAY UNIT	5	Tolerance	26
Reset the Display unit	5	Zoom	26
Navigation buttons	6	Halve or Zero set value	27
OK buttons	6	Live values – colours	27
Function buttons	6	Automatic recording	28
Status bar	7	Precision level E290 (Optional equipment)	28
Screen dump	8	Streaming values	29
LED lights	8	Calibration check	30
Battery	9	HORIZONTAL	31
Charge the Display unit	9	Mount the units	32
Charge and power the measuring units	9	Enter distances	34
Calculator	10	Measure using Easy Turn™	35
Measurement file handling	11	Measure using 9-12-3	36
Save file	11	Result and adjust	37
File manager	11	Thermal compensation	41
Favourites	12	RefLock™	42
Open file as template	13	Tolerance	43
Copy file to USB memory	13	MACHINE TRAIN (3)	45
Barcode	13	Enter distances	46
Print file (Optional)	14	Measure using EasyTurn™	47
Report	14	Measure using 9-12-3	48
Download file to PC	14	Result	49
Control panel	15	Result Machine view	49
Filter	15	Result Table view	50
Unit and resolution	16	Result Graph view	51
Detector rotation	16	Lock feet pair	52
Date and time	16	Best fit and Manual fit	52
Language	16	Uncertain coupling	52
User	17	Adjust	53
Backlight	17	Tolerance	55
Automatic power off	17	SOFTFOOT	57
VGA	18	VERTICAL	59
System update	19		
License	20		
Set up wireless connection	21		

Preparations	59
Measure	60
Result	61
Adjust machine	62
BTA	63
Measure using Display unit	65
Measure without Display unit	68
VIBROMETER	69
Measure	70
Vibration level	71
Bearing condition value	72
TECHNICAL DATA	73
Display unit E52	74
Measuring units	75
BTA E180 (Optional)	76
Charger	76

INTRODUCTION

Easy-Laser AB

Easy-Laser AB develops, manufactures and markets Easy-Laser® measurement and alignment equipment based on laser technology.

Intended use for the equipment is described in the technical data for each system. You find the technical data in the end of the manual.

Do not hesitate to contact us about your measurement problems. Our expertise will help you solve it in an easy way.

Limited warranty

This product is manufactured under Easy-Laser's strict quality control system. Should the product fail within three (3) years from the date of purchase under normal usage conditions, Easy-Laser will repair or replace the product free of charge.

1. Using new or refurbished replacement parts.
2. Exchange the product with a product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original product.

Proof of purchase date should be confirmed, and sent together with a copy of the original purchase document.

Warranty is valid under normal usage described in the user's manual appended with the product. The warranty comprises failure on Easy-Laser® product that could be related to material and/or fabrication errors. The warranty is valid only in the country of purchase.

The warranty is not valid in the following cases:

- If the product is broken due to mishandling or incorrect operation
- If the product has been exposed to extreme temperature, calamity, chock or high voltage.
- If the product has been modified, repaired or disassembled by unauthorized personnel.

Compensation for possible damage due to failure on Easy-Laser® product is not included in the warranty. Freight cost to Easy-Laser is not included in the warranty.

Note!

Before delivery of the product for warranty repair, it is the responsibility of the buyer to backup all data. Data recovery is not included in the warranty service and Easy-Laser is not responsible for data that may be lost or damaged during transit or repair.

Lithium Ion battery limited warranty

Lithium ion batteries inevitably lose power during their lifetimes, depending on usage temperatures and the number of charging cycles. Therefore, the internal rechargeable batteries used in the E-series are not included in our general 2-year warranty. There is a 1 year warranty for the battery capacity not to fall below 70 % (a normal change means that the battery must have more than 70 % capacity after more than 300 charging cycles). A 2 year warranty applies if the battery becomes unusable because of a manufacturing fault or factors that Easy-Laser AB could be expected to have control of, or if the battery displays abnormal loss of capacity in relation to use.

Safety precautions

Easy-Laser® is a laser instrument in laser class 2 with an output power normally less than 1 mW, which requires the following safety precautions:

- Never stare directly into the laser beam
- Never aim the laser beam at anyone else's eyes.

Note!

Opening the laser units can result in hazardous radiation, and will invalidate the manufacturer warranty.

If starting the machine to be measured would result in injuries, the possibility to unintentionally start it must be disabled before mounting the equipment, for example by locking the switch in the off position or removing the fuses. These safety precautions should remain in place until the measurement equipment has been removed from the machine.

Note!

The system should not be used in explosive risk areas.

Service and calibration

Easy-Laser products should only be repaired or calibrated by a certified service centre. Our main Service centre is located in Sweden. There are several local Service centres that are certified to carry out limited service and repair. Contact your local Service centre first before sending your equipment for service or repair. All Service centres are listed on our web site under Service and Calibration.

Before sending your measuring system to our main Service centre, please fill in the online Service and Repair report.

Disposal of old electrical and electronic equipment

(Applicable throughout the European Union and other European countries with separate collection programs)

This symbol, found on product or on its packing, indicates that this product should not be treated as household waste when disposed of.

It should be handed over to an applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed correctly, you will help to prevent potential negative consequences to the environment and human health. For more detailed information about the recycling of this product, please contact your local city office, household waste disposal service or the retail store where you purchased this product.



Manuals as PDF

You can download our manuals in pdf format from our website. The pdf's are also available on the USB memory stick that is delivered with most systems.

EasyLink

The new version of our database program EasyLink is available on the USB memory stick that is delivered with most systems. You can always download the latest version from easylaser.com>download>software.

Travelling with your measurement system

When travelling by airplane with your measurement system we strongly recommend that you check which rules apply for each airline company. Some companies/countries have limitations for checked baggage when it comes to items including batteries. For information about Easy-Laser® batteries, please see system unit details in the end of this manual. It is also good practice to remove the batteries from the equipment, when possible, e.g. D22, D23 and D75.

Specifications for built-in rechargeable batteries

Easy-Laser Part No.	Type	Voltage	Output	Capacity	Included in Part No.
03-0757	Li-Ion	3.7 V	39.22 Wh	10600 mAh	12-0418, 12-0700, 12-0748
03-0765	Li-Ion	3.7 V	2.5 Wh	660 mAh	12-0433, 12-0434, 12-0509, 12-0688, 12-0702, 12-0738, 12-0752, 12-0759, 12-0758, 12-0799, 12-0846
03-0971	Li-Ion	3.6 V	9.36 Wh	2600 mAh	12-0617, 12-0618, 12-0823, 12-0845
03-1052	Li-Ion	3.7 V	1.22 Wh	330 mAh	12-0746, 12-0747, 12-0776, 12-0777, 12-0791, 12-1054
12-0953	Li-Ion	3.7 V	7.4 Wh	2000 mAh	12-0944, 12-0943, 12-1028, 12-1029
12-0952	Li-Ion	7.4 V	39.22 Wh	5300 mAh	12-0961 (2 pcs)
12-0983	Li-Ion	3.7 V	7.4 Wh	2000 mAh	12-1026, 12-1027
N/A	Li-Ion	3.8 V	16.91 Wh	4450 mAh	12-1086

Compatibility

The E-series is not compatible with previous analogue units from the D-series. You can however continue to use previous brackets.

Disclaimer

Easy-Laser AB and our authorized dealers will take no responsibility for damage to machines and plant as a result of the use of Easy-Laser® measurement and alignment systems. If the system is not used as explained in this manual, the protection provided by the equipment may be impaired.

Copyright

© Easy-Laser 2018

We might change and correct the manual in later issues without further information. Changes to the Easy-Laser® equipment may also affect the accuracy of the information.

December 2018



Elisabeth Gårdbäck

Quality Manager, Easy-Laser AB

Easy-Laser AB, PO Box 149, SE-431 22 Mölndal, Sweden

Phone: +46 31 708 63 00, E-mail: info@easylaser.com

Web: www.easylaser.com

DISPLAY UNIT



- A** Connection for external power.
- B** USB A (master). Use for USB memory.
- C** USB B (slave). Use for connecting to a PC.
- D** Connection for Easy-Laser® equipment.

Reset the Display unit


Press and hold the On/Off button to reset the Display unit.

Charger


Only the charger supplied by Easy-Laser may be used.

Navigation buttons

To navigate on the screen, use the navigation buttons. The selected icon is marked with a yellow frame. The navigation buttons are also used to move between the icons in a submenu and to change the values in the fields.








OK buttons

There are two green **OK** buttons and they both work in the same way. Press  to select the currently selected icon for example.


Function buttons


The icons above the function buttons change depending on which view is currently displayed on screen.

Below is a list of the most common icons.

	Back to previous view. Press and hold to leave current program.
	Back. There is no “previous view”. Leave the current program.
	More. Contains a submenu with general functions, such as  (Control panel) and  (Save file).


Submenus

The icons formed as an arrow contain a submenu. Use the navigation buttons to navigate in a submenu. Press  to select.



Status bar

The Status bar contains additional information such as warning icon, current time and wireless connection.



There are also text messages regarding:

- The selected icon.
- Hints on what information you are expected to fill in.


Status bar icons

	Warning. Select the function button to get additional information regarding the warning.
	Warning. Displayed when the coordinates has been rotated in the detector. Go to Control panel to rotate coordinates.
	Hourglass. The Display unit is in the middle of a task.
	Display unit charging. Indicating that a power adaptor is plugged in.
	Display unit is low in battery.
	Measurement progress. Time depending on which filter you have selected.
	Selected filter.
	Peripheral. Indicates that a peripheral device is plugged in, such as a projector.
	Indicates that the wireless functionality is activated. The number beside indicates the number of wireless units connected.
	Printing report on thermal printer. The thermal printer is optional equipment.
	Printing performed OK.
	Printing problem.

Screen dump

It is possible to take screen dumps of what is currently displayed on screen. You can e-mail the screen dump or use it for reports.

Take a screen dump

1. Press and hold the numeric button period (.) for 5 seconds.
2. An hour glass is displayed on the status bar.
3. The screen dump is saved in the file system as a .jpg file. It is named with current date and time. Select  to open saved files. See “Measurement file handling” on page 11.

LED lights

Right indicator

Yellow	Flashing: The internal battery in the Display unit is charging.
---------------	---

Left indicator


Left indicator has several functions and colours:

Red/Blue	Quick flashing: Reprogramming the system.
Red	Flashing: Warning, for example low battery.
Blue	Flashing: Searching for detectors equipped with wireless functionality. Fixed light: Connected to detectors equipped with wireless functionality.
Green	Flashing: Display unit is starting. Fixed light: The internal battery in the Display unit is fully charged.
Light blue	Flashing: Backlight is off, but the Display unit is still on. Press any button to activate the Display unit.

Battery

Select  to display the Battery view.

When finished working for the day, charge the whole system. Plug in the power adaptor to the Display unit and connect the measuring units (**maximum two**) by using cable. If you use a split box, it is possible to charge up to eight units at a time.



The E-series is **not** compatible with units from the D-series.

Charge the Display unit

The Display unit can be used from -10°C to +50°C. Charge the Display unit within the temperature range of $\pm 0^\circ\text{C}$ to +40°C.

Note!

If you shut the Display unit off while charging, it will charge faster.


Power adaptor

With the power adaptor plugged in, you can keep on working.

Charge and power the measuring units




Use the splitter charge cable to charge or power the units.



- Charge the units by using the standard power adaptor.
- Power the units while measuring by using the USB connection to the Display unit.



Calculator



The calculator is found on the Start view and Control panel ().

1. Select  and  to open the calculator.
2. Use the numerical buttons and function buttons to enter values.
3. Use the  button to compute.




Unit converter

The unit converter is found on the Start view and Control panel ().




1. Select  and  to open Unit converter.
2. Select a category. Move using the navigation buttons up and down.
3. Press navigation button right. The result column is activated.
4. Select a unit to convert from.
5. Enter an amount. The other units are recalculated.

In the example below, one inch is selected.




Measurement **file handling**


Save file

1. Select  and  to save your measurement.
2. Enter a file name. The date and time will automatically be added to the file name.
The measurements that you save will be available to other users as well.
3. Press  to save the file.

File manager

Select  (found on the start view and Control panel) to open saved measurements. The File manager is displayed. Here you can easily when and from which program the file was saved.

Press  to open a measurement file.




















xml
A measurement file.

jpg
"Screen dump" on page 8

PDF
A report. The PDF report can not be opened in the Display unit.
PDF is not available for E420.






Function buttons

	Back to previous view.
	 " " on page 14.  "Open file as template" on page 13.  "Print file (Optional)" on page 14.
	 Sort files alphabetically.  Sort files by measurement program.  Sort by time.
	 Show all files.  Show only xml files.  Show only pdf files.  Show only jpg files.  Show only Favourites. See "Favourites" on page 12.
	"Copy file to USB memory" on page 13.
	Delete files. Delete all displayed files or only selected file.

Favourites

It is possible to save a measurement as a Favourite. A Favourite can be used for example when you have many flanges or machines with the same dimensions. This way you do not have to enter the same distances or tolerances every time. When you have saved as Favourite, a new icon is displayed on the start screen.



Create a favourite

1. Select  to open the File manager and select a file.
2. Select  and  to save the selected file as a Favourite.
3. Go to the start screen and select  to see all favourites.
4. Press  to open a Favourite. All distances are filled in.








Import favourites

The favourite files are saved in the folder Favourites in the Display unit.

1. Plug in the Display unit to a PC and open the Favourites folder.
2. Copy the .FAV (favourite) file to the root of an USB memory stick.
3. Connect the USB stick to a Display unit and select  and  to import.



Delete favourite

1. Select  to open the File manager and select a file.
2. Select  and  to show all Favourite files.
3. Select a file and .



Open file as template

You can open a saved measurement and use it to make a new measurement. This is very useful when you have many flanges or machines with the same dimensions for example. This way you do not have to enter the same distances every time.

1. Select  (found on the Start view and Control panel). The File manager is displayed.
2. Select a file in the list and select . The Edit distance view is displayed.
3. Change distances if needed and proceed to measuring view.

Copy file to USB memory


You can easily copy a saved measurement or other files to a USB memory.


1. Insert a USB memory.
2. Select the file you want and select .
3. A folder is automatically created on the USB memory. The file is saved in the folder \Damalini\archive\.

Barcode

Save file with barcode

The barcode scanner is not included in all systems. The first time you measure a machine, you stick a barcode on the machine and save the measurement together with the scanned barcode. Next time you align the same machine, all you need to do is scan the barcode and all machine data is read.

1. Scan the barcode on the machine.
2. Enter a file name.
3. Press  to save the file. All measurement data is saved together with the barcode.




The barcode number is added to the file name.

Open file with barcode

- Start the Display unit and scan the barcode. The **latest** measurement that was made and saved with this barcode is automatically opened.



OR




- Select  to open File view. Scan the barcode on the machine. **All** measurements saved with this barcode are shown.


Print file (Optional)

Part no. 03-1004

The thermal printer is optional equipment.

1. Save the measurement. To print from a Shaft program, you need to open a saved measurement before you can print a report.
2. Connect the thermal printer and select  and .
3. The progress is displayed on the status bar.

	Printing report on thermal printer.
	Printing performed OK.
	Printing problem.



You can also save a measurement, download the pdf-report to your PC and print the pdf-report.

Report

A report is generated and saved in the filing system. You can not open an old measurement and save it again (program Machine train is an exception to this). You can however generate a new report from an opened file. This means you can for example change the language and make a new report from the opened measurement. You can download the report to a PC and print it.

Company logo

You can replace the logo on the report with your own .jpg file.

1. Name your logo logo . jpg. The default logo has the proportions of 230x51 pixels.
2. Connect the Display unit to your PC using the USB-cable.
3. Place your image in the Display unit's folder Damalini / custom / reports / logo.

File extensions (for example .jpg) are often hidden in the Explorer window. To display file extensions do the following: Open an Explorer window and press Alt to show menu. Select Tools > Folder options. Click the View tab > Advanced settings > Clear the Hide extensions for known file types check box.

Date format

By default, the date and time format is set to Central European Time (CET).

You can change the date and time format used in your PDF reports.



Download file to PC

1. Start the Display unit. It is important to let it start fully before connecting the cable.
2. Connect the USB cable between the Display unit and PC.
3. While you have this connection, the Display unit is blocked.
4. View and/or copy the files to the PC.

EasyLink

You can also use our database program EasyLink to view the files on your PC. EasyLink is available on the USB memory stick that is delivered with most systems. You can always download the latest version from easylaser.com>lifecycle support>software download.

Control panel

Select  and  to open the Control panel. Some of the settings are personal and will be default next time you start the system.



Note!


All settings are not available for all systems.

Filter

Select  to open the Filter view.

The filter you select on the Filter view will be saved as a personal setting.

If the laser beam passes through air with varying temperature, this may influence the direction of the laser beam. If measurement values fluctuate, this could mean unstable readings. Try to reduce air movements between laser and detector by, for instance, moving heat sources, closing doors. If the readings remain unstable, increase the filter value (more samples will become available to the statistical filter).



Select filter

Use as short a time as possible that still produces acceptable stability during the measurement. Default is set to 1. Normally you will use a filter value of 1-3. If you set the filter type to 0, no filter will be used.


Use the numerical buttons 3, 6 and 9 to set the filter. In the Filter view but also when you are using a measuring program.



Use numerical buttons to select filter

Current noise level in the system before and after filtering

Press function button 6 to test how long the measurement progress is




Currently selected filter


Use numerical buttons to set filter. Button 6 will restart the filter

Graph shows filtered noise level over time

Unit and resolution

Personal setting

Select  to open the Units and resolution view. Use the navigation buttons to move between the fields. Set Metric or Imperial and which resolution you want to use. Default is set to 0.01 mm (0.4 mil). The selected unit is shown on the Status bar.




Note!


It is possible to select 0.0001mm only in the E940 system.

For E420, only 0.01mm is possible.

Detector rotation

Personal setting


The coordinate system can be rotated 90°. Select  to open the Detector rotation view. When you have rotated the coordinates, a warning is displayed on the Status bar. Detector rotation will only affect detectors with two axis.




Warning displayed on Status bar

Detector rotation view

Date and time



Select  to open the Date and Time view. Set the date and time. Default is set to Central European Time. (CET)




Date and time view

Language

Personal setting




Select  to open the Language view. Default is set to English. Use the navigation buttons to select a language. Press  to save changes.




Language view

User

Select  to open the Users view. A user account is used for storing your personal settings.



Use the function buttons   to add or remove users. To switch user, simply select the user you would like to switch to and press .



User view

Backlight

Personal setting

Select  to open the Backlight view. Use the navigation buttons to move between the fields. Press  to save changes. When backlight is off, the left LED signal will flash to indicate that the Display unit is still on.

Backlight level


Adjust the backlight to make it easier to read in bright sunlight. Remember however that a high contrast consume more battery power. Default is set to 50%.

Reduce after

Set time before backlight reduction as a way to save energy. The Display unit will be dimmed, but is still on. Default is set to Never.

Off after



Set time before backlight off. Default is set to Never.




Backlight view

Automatic power off

Personal setting

Select  to open the Automatic off view. Select how much time before automatic power off. Use the navigation buttons to select. Press  to save changes.




Automatic power off view

Note!

Measurements in progress will not be saved in the event of an Automatic power off.

Information

Select **i** to display the information regarding serial number and version of the equipment.




Information view

VGA

(Not available on all systems.)

Makes it possible to show display unit screen image with a projector, for example in a training context. Must be factory installed on order.


Select  to open the VGA view.



System update





Download update file


1. Go to easylaser.com>lifecycle support>software download.
2. Download the update file to your PC.
3. Unzip the file.
4. Copy the .elu file to the root of a USB memory.



Save .elu file on a USB memory.

Install update file

1. Start the Display unit. Make sure that the internal battery of the Display unit is charged. The battery symbol should be at least yellow.
2. Insert the USB memory in the Display unit. Do not remove the USB memory until the update is finished.
3. Select  and  to display the System update view.
4. Select the update file and press .
5. Select . The installation starts.
6. The Display unit will automatically restart when the installation is finished and the Main menu is displayed.



Select the .elu file.

Note!

During restart, the screen turns black for up to one minute. When the main menu is displayed, it can “freeze” (no response when you press buttons). If this happens, press the On/Off button for at least 15 seconds to restart the Display unit.




Main menu is automatically displayed after restart.

Font package

Some of the early E-series systems was not installed with Unicode fonts. To install the latest system updates, you need to install the font package with Unicode fonts.

Check if you need to install:

1. Select  and  to display the Language view.
2. Check if you have Chinese installed. **If Chinese is installed, you already have the correct Font package.** If not, please go to easylaser.com>lifecycle support>software download and follow the instructions above to install.





Chinese installed?
No need to update with Font package.


License



It is easy to upgrade your Display unit.

1. Contact your Easy-Laser® distributor if you wish to upgrade your Display unit.
2. An e-mail will be sent to you with information on how to download the update file.
3. Save the file to the root of the file system to a USB memory stick or directly to the Display unit.

Save file on USB


1. Save the downloaded license file to a USB memory stick.
2. Insert the USB memory stick in the Display unit.
3. Select  and  to display the License view.







4. Select  to search for licenses.
5. Press  to import license.

Save file to Display unit

1. Connect the Display unit to a PC.
2. Save the license file to the root of the Display unit's storage.



3. Select  and  to display the License view.
4. Select  to search for the new license file. A window is displayed.
5. Disregard the text and select . The license file is installed and full functionality is achieved.

Set up wireless connection



Wireless technology makes it possible for Display unit and Detector to exchange data without using cables.




Some detectors have built-in wireless functionality, others have a separate unit that you attach to the detector. *Please see Technical data for more information.*



Set up

This is only necessary when adding new units to the list.

1. Select  to open the wireless view.
2. Select  to search for units.
3. The view is updated with the units you can connect to.









Searching for wireless units

4. Select the unit you want to connect to and select . The unit will automatically be connected when you start a measurement program.
5. Press  to save changes and to leave the view.
6. Enter a measurement program. The Display unit will connect to the selected units. While connecting, the left LED indicator is flashing with a blue light which will turn to a fixed blue light once connected.
7. An icon on the status bar will indicate how many wireless units that are connected.



One unit connected



Function buttons




	Back to Control panel. Changes made in the table are saved.
	Search for wireless units.
	Cancel search. Use if your unit is already found.
	Remove a unit from the list.
	Connect the unit. The unit will automatically connect when you start a measurement program.
	Disconnect the unit. The unit will remain in the list.

Note!

Do not use a wireless unit and a cable at the same time.

Use only one wireless unit

Many of our systems are delivered with two Measuring units. In some cases you might want to use only one unit together with a laser transmitter. By default both units are set to “Connect ”. If the unused unit is set to “Connect ”, the system will keep on trying to connect to it, even if it is not plugged in.

1. Attach the wireless unit to the detector.
2. Select  to open the wireless view.
3. Set the unit you want to use to .
4. Make sure that the other units are set to .
5. Enter a measuring program.

The Display unit will connect to the selected unit. This may take a couple of minutes.

Note!

Remove the wireless unit from the Measuring unit before putting the equipment in the carrying case. If attached, it will discharge the Measuring unit.

Wireless information

This device contains

FCC ID: PVH0946

IC: 5325A-0946

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions;

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

CHOOSE PROGRAM

Preparations

Before starting a measurement, there are several things that are good to check to ensure a good and accurate measurement.

- Ensure a good measurement environment. Strong sunlight, warning lights, vibrations and temperature gradients can affect the readings.
- Make sure the surfaces are clean.
- Ensure that the foundation of the machine is stable.
- Check for play and clearance in the bearing.



Values

Shows live readings from S and M units.



Horizontal

For alignment of horizontal machines.



9-12-3. Measuring positions are registered at positions 9, 12, 3 o'clock.

EasyTurn™. Measuring positions are registered within 40°.



Machine train 3

For for machines mounted in a train with two couplings.



Softfoot

Check to ensure that the machine is resting evenly on all its feet.



Vertical

For alignment of vertically mounted machines.



BTA

For alignment of belt and chain drives.



Vibrometer


Shows the vibration level in "mm/s" and bearing condition value in "g".

PROGRAM VALUES

V 0.00
H 0.00

With the program Values, you can see live readings from the detectors.
As default, a target and a table is displayed.

Press **OK** to register values.





Function buttons


	Back, leave program.
	See "Control panel" on page 15. See "Tolerance" on page 26. See "Zoom" on page 26. Save file. See "Measurement file handling" on page 11. See "Automatic recording" on page 28. Delete registered values. Print report on thermal printer (optional equipment). See "Calibration check" on page 29.
	Set current value to zero.
	Halve displayed value.
	Return to absolute value. Only available after zeroing or halving.
	Choose how to display values. Use left and right navigation button to switch between two or more detectors when only one target is displayed.

Note!


The M-unit can be used as a detector together with a laser transmitter. Do not use the S-unit for this.

Tolerance


1. Select  and  to set tolerance.
It is possible to set different tolerance in vertical and horizontal direction.
2. Use navigation buttons to move between the fields and to change the tolerance.
3. Press **OK**.





Live values and marking displayed in green when within tolerance.





Live values displayed in red when outside tolerance.




Zoom

1. Select  and  to zoom.
2. Select a zoom factor between 1–5. Use navigation buttons to increase or decrease zoom factor.
3. Press **OK**.



Default view



Zoom factor is set to 3

Edge warning

When the laser beam is close to the edge, the edge is “lit up” as a warning. It is not possible to register values when you see the edge warning.



Halve or Zero set value

Half value

Select $\frac{1}{2}$ to half displayed value.

Zero line of the PSD moves halfway towards the laser line.

Zero set value



Select 0 to zero set displayed value.

Zero line of the PSD moves to the laser line.


Absolute value

Select $\frac{1}{1}$ to return to the absolute value.

Zero line of the PSD returns to the PSD centre.



Note the change of the current range







Live values – colours

Live values are yellow

Green when within tolerance



Red when outside tolerance


Loss of signal, laser beam interrupted for example




Automatic recording

In Values, it is possible to make automatic recording of values. This is very useful when you want to register values during a longer time period for example.

1. Select  and  to start automatic recording.
2. Set Interval.
3. Press navigation button “right”.
4. Set Duration.
5. Press **OK**. The recording will start and you can follow the progress on screen.



Icon indicates that values are being recorded



Views

You can decide how to display the current values. As default a target and a table is displayed, but you can choose to show only target for example.


Select  to display the different layout options, see image below.

Note!


Use left and right navigation button to switch between two or more detectors when only one target is displayed.

Precision level E290 (Optional equipment)

Connect the Precision level, see “Set up wireless connection” on page 21.




When measuring a shaft using the Precision level, we recommend that the shaft is no larger than 100 mm in diameter.



Streaming values




With the Streaming value functionality, you can transfer data from the Display unit. For this to work, you need a USB to USB Null Modem Cable, the USB cable delivered with the system does not work for streaming values.


1. Connect the Display unit to the PC using a USB to USB Null Modem Cable.



The USB-to-USB null modem cable shows up as a Virtual Serial Port with the following properties:
19200 bps, 8n1 without flow control.

The port number can, for example, be found using the Device Manager. See 'USB Serial Port' under 'Ports (COM and LPT)'.

2. Click Open.
3. Start the program Values in the Display unit.
4. Select  and  to start streaming values.
5. To stop, select .



In this example, PuTTY is used to show the streamed data

Data format

The data is sent as lines with semi colon separated values. Each line begin with a detector identification, S, M, Vib or BTA, followed by the detector serial number. The unit and resolution depends on the settings in the user profile.

Data from Vib: Vib;serial;LP;HP;G;

Data from BTA: BTA;serial;PSD1X;PDF2X;PDF3X;X axis angle;Y axis angle;Z axis angle;




Data from S: S;serial;PSD X; PSD Y; X axis angle;Y axis angle;Z axis angle;


Data from M: M;serial;PSD X; PSD Y; X axis angle;Y axis angle;Z axis angle;

Calibration check

Use the program Values to check if the detector readings are within specified tolerances.


Quick check

1. Set the tolerance to 0.01 mm (0.5mil).
2. Select  and show targets for both M- and S-unit.
3. Select  to zero set value.
4. Place a shim under the magnet base to lift the M-unit 1mm (100mils). The M-unit's reading shall correspond to the movement within 1% (1mil \pm 1 digit) (0.01mm \pm 1 digit).
5. Remove the shim from the M-unit.
6. Select  to zero set value.
7. Make a mark to mark out the position of the detector.
8. Place the shim under the magnet base of the S-unit.
The S-unit's reading shall correspond to the movement within 1% (1mil \pm 1 digit) (0.01mm \pm 1 digit).



Note!


The shim must be exactly 1 mm. In this example it is only the M-unit that is checked.




Zero set value

Select to show both targets.

Precision check

1. Fasten one unit in a machine tool.
2. Select  to zero set value.
3. Move the units a known distance is to use the movement of a machine tool spindle.
4. The fastened unit's reading shall correspond to the movement within 1% (1mil \pm 1 digit) (0.01mm \pm 1 digit).



Note!

In this example it is only the unit fastened in the machine that is checked.

HORIZONTAL



For horizontally mounted machines.

Select between three different measuring methods:



EasyTurn™

Start anywhere on the turn. The three measuring positions can be registered with as little as 20° between positions. By default, the EasyTurn program is shown.

See “Measure using Easy Turn™” on page 35.



9-12-3


The measuring positions are registered at positions 9, 12, 3 o'clock. The inclinometers are not used.

“Measure using 9-12-3” on page 36.

Note!



Measurements made with older versions of the Horizontal program are opened with the older version of the program. For information regarding the previous program version, please see corresponding manual.

Work flow



Mount the units


1. Mount the S-unit on the stationary machine and the M-unit on the movable machine.
2. Mount the units facing each other. Make sure they are at the approximately same rotational angle.



You need to place the measuring units with an offset, see image.

Wireless

The Display unit is equipped with wireless technology, which makes it possible for the Display unit to receive data without using cables.




Face the stationary machine (S) from the movable machine (M). Then 9 o'clock is to the left, as in the measuring programs.

Adjust measuring units


Place the Measuring units on the rods, make sure they are at the approximately same rotational angle and radius. You need to place the measuring units with an offset, see image. Also make sure that the adjustment knob is adjustable in both directions.

Note! Image showing measuring units for system E530.


1. Place the Measuring units at 9 o'clock. Adjust the laser line to the centre of both targets. Use the adjustment knobs and/or move the detectors on the rods.




2. Turn the shafts 180°. Make a mark on the rods or machine halfway between the laser line and centre of both targets.




3. Adjust the laser beams half way to the centre of targets. Use the adjustment knobs and/or move the detectors on the rods.



4. Adjust the movable machine until the laser beam hits the centre of both targets.





5. Turn the shafts 180°. Check if both laser lines hit the targets. If not, repeat step 3–5.






Turn shafts to 12 o'clock. Repeat all steps for vertical adjustment.












Enter distances

Confirm each distance with .



1. Distance between first and second feet pair. Optional, select  to activate field.
2. Distance between second feet pair and S-unit. Optional, select  to activate field.
3. Distance between S-unit and M-unit. Measure between the rods.
4. Distance between S-unit and centre of coupling.
5. Distance between M-unit and feet pair one.
6. Distance between feet pair one and feet pair two.
7. Coupling diameter. Optional, select  to activate field.


Function buttons

	Leave program.
	 See "Control panel" on page 15.  See "Tolerance" on page 43.  See "Thermal compensation" on page 41.  Select to enter distances of the S-machine.  Toggle between showing Distance view in 3D or 2D.
	Diameter. Select to enter coupling diameter. This is necessary if you want the result based on the gap of the coupling instead of angle.
	Add a feetpair.
	Toggle button. Show movable machine to the left or the right.
	Continue to Measure view. Available when you have entered the mandatory distances.






Measure using 9-12-3


Preparations

Follow the preparations as described in the previous pages.

- 1. Mount the measuring units.
- 2. Enter distances, confirm each distance with .
- 3. If needed, perform a rough alignment.
- 4. If needed, perform a Softfoot check.








Measure

- 1. Select  and  to switch to 9-12-3.
- 2. Adjust laser to the centre of the targets. If needed, adjust the units on the rods, then use laser adjustments knobs.
- 3. Turn shafts to 9 o'clock.
- 4. Press  to register first position. The first position is automatically set to zero.
- 5. Turn shafts to 12 o'clock.
- 6. Press  to register second position.
- 7. Turn shafts to 3 o'clock.
- 8. Press  to register third position. The Result and adjust view is displayed. See "Result and adjust" on page 37.




Edge warning
When the laser beam is close to the edge, the edge is "lit up" as a warning. It is not possible to register values when you see the edge warning.

Function buttons

	Back. Measure previous position or back to Distance view.
	See "Control panel" on page 15.
	 Switch to the EasyTurn™ method.
	 Switch to the 9-12-3 method.
	 Switch to the Horizontal Multipoint method.
	See "SOFTFOOT" on page 57.

Result and adjust

Offset, angle and feet values are clearly displayed. Both horizontal and vertical direction are shown live, which makes it easy to adjust the machine. Values within tolerance are green.



Function buttons


	Back to measure view.
	See "Control panel" on page 15. Save, see "Measurement file handling" on page 11. See "Tolerance" on page 43. See "Thermal compensation" on page 41. Show target. This is a quick way to see where the laser beam hits the target and how the measuring units are positioned. Print report on thermal printer (optional equipment). Available when you open a saved measurement. Edit distances. Press to confirm changes. The result is recalculated.
	RefLock, lock feet. <i>Note! Not available for E420.</i>
	See "Live values" on page 38. Toggle button. Show/hide Position indicator. See "Position indicator" on page 39.
	Toggle button. Switch between to show gap and show angular error per 100 mm. For this to work you need to set the coupling diameter.

Live values

When reading the values, face the stationary machine from the movable machine.

Positions for measuring units as seen from the movable machine.

Live values are marked with yellow frame.




Face the stationary machine (S) from the movable machine (M). Then 9 o'clock is to the left, as in the measuring programs.

Offset and angle values

The offset and angle value indicate how well the machine is aligned at the coupling.

They appear in both horizontal and vertical direction.

These values are important to get within tolerance.




Offset

The centre lines of two axis are not concentric but parallel.

This is measured at the coupling centres.


In this example, a positive offset is shown.



Angular misalignment

The centre lines of two axis are not parallel.

In this example, a negative angle is shown.



Offset and angular misalignment

Misalignment is often a combination of both offset and angular misalignment.

Show live values for EasyTurn™

The inclinometer can be used to show live values at all angles.



Show live values at any angle.



Inclinometer controls when to show live values.

Show live values for 9-12-3

The inclinometer is not used. You can manually show in which position your measurement units are.

Select  to show the live options.



Force live to 6 o'clock.



Force live to 12 o'clock.




Force live to 3 o'clock.



Force live to 9 o'clock.


Adjust


Adjust the machine if needed.

- 1. Shim the machine according to the vertical feet values.
- 2. Adjust the machine sideways according to the live horizontal values.
- 3. Tighten the feet.
- 4. Select  to remeasure.






Position indicator

To adjust, you need to place the measuring units in live position (9, 12, 3 or 6 o'clock).

Select  to show the Position indicator.






Function buttons


	Toggle button. Show/hide position indicator manually.
	
	Toggle button. Select  to display the position indicator automatically when you move the measuring units.
	

Result table

With the result table, you can measure the same coupling several times and document the results.

1. Measure using Easy-Turn, 9-12-3 or Multipoint.
2. Go to the Result view.
3. Select  to remeasure the coupling. Remeasure as many times as needed.
4. Go to Result view and select  and  to open the result table.

Once you have opened the result table, the information will also be included in the report. The three latest measurements are visible. If you have more, use the navigation buttons to scroll.



Result table 09:30 mm 5

#	Vertical		Horizontal		Note
	Offset	Angle	Offset	Angle	
1	0.13	0.08	-0.01	0.16	As found 1.
2	0.21	0.10	-0.02	0.15	
3	0.23	0.11	-0.02	0.15	

The table is shown in the report

Remove the table from the report

Edit note

Angle or Gap is displayed.




Add notes to the measurements

The three latest measurements are visible. No live values are visible in the report.




#	Vertical		Horizontal		Note
	Offset	Gap	Offset	Gap	
1	0.13	0.05	-0.01	0.11	As found 1.
2	0.21	0.07	-0.02	0.10	
3	0.23	0.07	-0.02	0.10	
4	0.22	0.07	-0.02	0.10	
5	0.17	0.06	-0.02	0.10	

The table is included in the report

Add a note

1. Select a measurement.
2. Select  or  to write or edit a note.
3. Press  to save the note.

Function buttons

	Toggle button. Show/hide the result table in the report.
	Add (or edit) a note for the selected measurement.
	Delete the selected measurement.

Save


You can save a measurement and open it later to continue to measure. When you save the measurement again, it will **not** overwrite the earlier version.

When you save a measurement, a pdf is automatically generated.

See "Measurement file handling" on page 11.

Thermal compensation

During normal operation, machinery is influenced of different factors and forces. The most common of these changes is the change in the temperature of the machine. This will cause the height of the shaft to increase. This is called thermal growth. To compensate for thermal growth, you enter values for cold condition compensation.

Select  and  from the result and distance view. The Thermal compensation view is displayed.

Example

It can be necessary to place the cold machine a bit lower to allow thermal growth. In this example we assume a thermal growth of +5mm in **HOT** condition. Therefore we compensate with -5mm in **COLD** condition.

1 Before thermal compensation.


2 Set thermal compensation.

Indicates that the compensation values are set for cold (offline) condition.


Vertical offset and angle for movable machine.

3 Thermal compensation set. When you have set thermal compensation and return to the result view, the values have changed. When the machine becomes warm, the thermal growth will make it perfectly aligned.

Indicates that thermal compensation has been set




Feet values

1. On the distance view, enter distances for the S-machine.
2. Select .
3. Set thermal compensation values based on feet values. The coupling values are recalculated. If there are more than two feet pairs, you enter values for the first and last feet pair.






Note!


Only the coupling values are visible in the PDF report and the printed report.



RefLock™

From the result view, you can select the function RefLock™. Here you can choose any two feet pairs as locked and thus choose which machine is to be used as stationary and which as adjustable. If you want to lock feet pair on the stationary machine, you need to enter distances.

1. Select  and .
2. The RefLock graph view is displayed. Navigate using the left and right navigation button.
3. Select  to lock the selected feet pair or  to unlock.
4. Select  to continue to the result view.




Note!





RefLock™ is available when using the program Horizontal. Not available for programs Vertical or Cardan.

Tolerance

1. Select  and . The tolerance window is displayed.
2. Select a tolerance and press .






Function buttons

	Close Tolerance view.
	See "Control panel" on page 15.
	Edit user defined tolerance.
	Delete user defined tolerance.

Add new tolerance

You can add your own user defined tolerance.

1. Select the row "Add new tolerance". Press .
2. Enter name and tolerance.
3. Press . The new tolerance is added to the list.



Tolerance in result views

The tolerances are clearly displayed in the result views.

Green = within tolerance

Red = not within tolerance

Tolerance table

The rotation speed of the shafts will decide the demands on the alignment. The table on this side can be used as a guidance if no other tolerances is recommended by the manufacturer of the machines.

The tolerances is set to the maximum allowed deviation from accurate values, with no consideration to if that value should be zero or compensated for thermal growth.

Offset misalignment

rpm	Excellent		Acceptable	
	mils	mm	mils	mm
0000-1000	3.0	0.07	5.0	0.13
1000-2000	2.0	0.05	4.0	0.10
2000-3000	1.5	0.03	3.0	0.07
3000-4000	1.0	0.02	2.0	0.04
4000-5000	0.5	0.01	1.5	0.03
5000-6000	<0.5	<0.01	<1.5	<0.03

Angular misalignment

rpm	Excellent		Acceptable	
	mils/"	mm/100mm	mils/"	mm/100mm
0000-1000	0.6	0.06	1.0	0.10
1000-2000	0.5	0.05	0.8	0.08
2000-3000	0.4	0.04	0.7	0.07
3000-4000	0.3	0.03	0.6	0.06
4000-5000	0.2	0.02	0.5	0.05
5000-6000	0.1	0.01	0.4	0.04

The higher the rpm of a machinery is, the tighter the tolerance must be. The acceptable tolerance is used for re-alignments on non-critical machinery. New installations and critical machines should always be aligned within the excellent tolerance.

Note!


Consider these tables as guidelines. Many machines must be aligned very accurately even if they have a lower rpm. For example gearboxes.

MACHINE TRAIN (3)




For alignment of machine trains with three machines. You can pick the reference machine manually, or let the program choose one that will minimize the need for adjustments.


Work flow










Enter distances

Confirm each distance with .








- ① Distance between first and second feet pair.
- ② Distance between second feet pair and S-unit.
- ③ Distance between S-unit and centre of coupling.
- ④ Distance between S-unit and M-unit. Measure between the rods.
- ⑤ Distance between M-unit and feet pair one.
- ⑥ Distance between feet pair one and feet pair two.
- ⑦ Coupling diameter. Optional, select  to activate field.


Function buttons

	Leave program.
	 See “Control panel” on page 15.
	 See “Tolerance” on page 55.
	 See “Thermal compensation” on page 41.
	Diameter. Select to enter coupling diameter. This is necessary if you want the result based on the gap of the coupling instead of angle.
	Continue to Measure view.

Measure using EasyTurn™

It is possible to measure with as little as 40° spread between the measurement points. However, for an even more accurate result, try to spread the points as much as possible. The colours indicates where the optimum positions to measure are.






1. Adjust laser to the centre of the targets. If needed, adjust the units on the rods, then use laser adjustments knobs.
2. Press  to register first position. The first position is automatically set to zero. A red marking is displayed.
3. Turn shafts outside of the red 20° marking.
4. Press  to register second position.
5. Turn shafts outside of the red markings.
6. Press  to register third position. The Result and adjust view displayed.
7. The result is displayed. You can show the result as graph, table or machine view.
See chapter Result.
8. From the result view, select  to measure next coupling. If you want to adjust the coupling, select the machine you want to adjust and press . *See chapter Adjust.*








Edge warning

When the laser beam is close to the edge, the edge is "lit up" as a warning. It is not possible to register values when you see the edge warning.



Function buttons

	Back. Measure previous position or back to Distance view.
	See "Control panel" on page 15.
	Switch to the EasyTurn™ method.
	Switch to the 9-12-3 method.
	See "SOFTFOOT" on page 57.







Measure using 9-12-3

- 1. Select  and  to switch to 9-12-3.
- 2. Adjust laser to the centre of the targets. If needed, adjust the units on the rods, then use laser adjustments knobs.
- 3. Turn shafts to 9 o'clock.
- 4. Press  to register first position. The first position is automatically set to zero.
- 5. Turn shafts to 12 o'clock.
- 6. Press  to register second position.
- 7. Turn shafts to 3 o'clock.
- 8. Press  to register third position.




- 9. The result is displayed. You can show the result as graph, table or machine view. See "Result" on page 49.
- 10. From the result view, select  to measure next coupling. If you want to adjust the coupling, select the machine you want to adjust and press . See "Adjust" on page 53.

Function buttons

	Back. Measure previous position or back to Distance view.
	See "Control panel" on page 15.
	 Switch to the EasyTurn™ method.
	 Switch to the 9-12-3 method.
	Softfoot.

Result




You can show the result as graph, table or machine view.

By default the machine view is displayed. Navigate in the result views by using the navigation buttons.

Result Machine view

Select and . The Machine view is displayed.



Feet pair

If there are more than three feet pairs, values are only displayed for the first three pairs in this view. To view values for all feet pairs, switch to Table view.

Adjust coupling


Select the machine you want to adjust and press . See “Adjust” on page 53.

Function buttons












	Remeasure the coupling. Press and hold to leave program.
	See “Control panel” on page 15.
	Save file. “Measurement file handling” on page 11.
	See “Tolerance” on page 55.
	See “Thermal compensation” on page 41.
	View and edit distance.
	Print. “Measurement file handling” on page 11.
	Toggle button. Show Gap or Angle values.
	Switch result view.
	Measure next coupling.

Result Table view

Select  and . The Result Table view is displayed.
Navigate using the navigation buttons.



Function buttons

	Remeasure the coupling. Press and hold to leave program.
	See "Control panel" on page 15.
	Save file. "Measurement file handling" on page 11.
	See "Tolerance" on page 55.
	See "Thermal compensation" on page 41.
	View and edit distance.
	Print. "Measurement file handling" on page 11.
	Toggle button. Show Gap or Angle values.
	Lock / unlock feet pair. Available when you show feet values. See "Lock feet pair" on page 52.
	Toggle between showing feet or coupling values.
	Switch result view.

Save


You can save a measurement and open it later to continue to measure. When you save the measurement again, it will **not** overwrite the earlier version.

When you save a measurement, a pdf is automatically generated only when the whole train has been measured.










See "Measurement file handling" on page 11.

Result Graph view

Select  and . The Graph view is displayed.



Function buttons

	Remeasure the coupling. Press and hold to leave program.
	See “Result Machine view” on page 49.
	Lock / unlock feet pair. If you can not adjust a feet pair, use the lock function. See “Lock feet pair” on page 52.
	Toggle between showing horizontal or vertical graph.
	Switch result view.
	Available when you have measured the whole train. See “Best fit and Manual fit”.
	Best fit
	Manual fit
	Select to measure next coupling.

Lock feet pair



This function is available in graph and table view. We recommend that you lock two feet pair to get the most accurate calculated reference line as possible. If you choose to lock only one feet pair, the tilt of the train is maintained and the coupling is offset.


Best fit and Manual fit

By default, an average best fit is calculated on the measured machine train. This means that the train is tilted to the flattest possible plane. If no feet pairs are locked, the system assumes that all machines are possible to move in all directions. For each coupling that you measure, the best fit is recalculated. When you have made adjustments on a coupling, the best fit is no longer recalculated.


Manual fit


Only available when you have measured the whole train, and only in graph view. Use this function when you know that you for example can move a machine a little in one direction, but not at all in another direction.

1. Select  and  to activate the Manual fit function. If there are locked feet pair, these are unlocked.
2. Use the numerical buttons to move the graph.
 - Buttons 1 and 4 move the left part of the train
 - Buttons 2 and 5 moves the whole train.
 - Buttons 3 and 6 moves the right part of the train.
 - Button -+ will change the scale.

To return to average best fit, select  and .


Uncertain coupling

When you adjust one coupling, it might affect the next coupling in the machine train. In the example below, the coupling A - B has been adjusted, which might have an affect on the coupling B - C. This is indicated with the symbol . When you remeasure or adjust the coupling, the warning is removed.



Adjust

You can adjust a machine even though you have not measured the whole train.



1. Select the machine you want to adjust and press .
If you just measured the coupling, the Adjustment view is displayed. If not, you need to remeasure the coupling first and the Measure view is displayed.
2. Adjust the machine.
3. Select when you are done. The Measure view is displayed.
4. Remeasure the coupling to confirm the adjustment.

Select coupling tolerance

10:32 mm

A B C

Offset and angle

Adjusting coupling A-B

11:00 mm

Live

0.07 0.17 /100






Feet values.
Yellow frame indicates live values.

Add shims


Remove shims

0.01 -0.02 0.01 0.02

Function buttons


	Back to result view.
	See “Control panel” on page 15.
	Toggle button. Select to show/hide Position indicator. See “Position indicator” on page 39.
	See “Live values” on page 38.
	Continue. You need to remeasure the coupling to confirm the position of the measuring units.

Uncertain coupling

When you adjust one coupling, it might affect the next coupling in the machine train. This is indicated with the symbol .


Scale

The scale of the graph might change when you have made adjustments.







Tolerance

1. Select  and . The tolerance window is displayed.
2. Select a tolerance and press . The next coupling in the train is selected.






Function buttons

	Close Tolerance view.
	See “Control panel” on page 15.
	Edit user defined tolerance.
	Delete user defined tolerance.

Add new tolerance


You can add your own user defined tolerance.

1. Select the row “Add new tolerance”. Press .
2. Enter name and tolerance.
3. Press . The new tolerance is added to the list.



Tolerance in result views

The tolerances are clearly displayed in the result views.




SOFTFOOT






Perform a softfoot check to ensure that the machine is resting evenly on all its feet. A softfoot can be angular and/or parallel, see image.

Softfoot can be caused by:





- Twisted machinery foundations.
- Twisted or damaged machinery feet.
- Improper amount of shims under machine feet.
- Dirt or other unwanted materials under machine feet.




Start Softfoot from main shaft menu









1. Select  and .
2. Enter distances.
3. Select  to continue.

Start Softfoot from Horizontal program

1. Select  and  to open Horizontal program.
2. Enter distances. Confirm each distance with . To perform a Softfoot check, you need to enter distances between the feet pairs. The measure view is displayed.
3. Select . Softfoot is only available before you have registered any measurement points.



Function buttons


	Leave program.
	 See "Control panel" on page 15.  Enter distance for S-machine. Makes it possible to perform a soft-foot measurement on the S-machine.  Toggle between 3D and 2D view.
	Add a feet pair. Only available for E540. In E710/E720 you select machines and optional number of feet when you select custom.
	Toggle button. Show movable machine to the left or the right.
	Continue to Measure view. Available when you have entered the distances.

Filter

When you measure Softfoot, the detector filter is increased by three steps (maximum to filter 7). If you measure with a higher filter than 7, that filter will remain. When the Softfoot measurement is done, the filter is restored.

Measure softfoot

1. Tighten all feet bolts.
2. Turn the measuring units to 12 o'clock.
3. Adjust laser to the centre of targets. If needed, adjust the units on the rods, then use laser adjustments knobs.



Turn the measuring units to 12 o'clock.

Adjust laser line to centre of target.

4. Press . The Softfoot measure view is displayed. The first bolt is marked with yellow.
5. Loosen and then retighten the first bolt.
6. Press to register value.
7. Register values on all four feet. The result is displayed.
8. Shim the foot with the largest movement.
9. Do a Softfoot check again.

Measure:

Loosen and retighten bolt before register value.



Result:

Arrow indicating that the machine is tilting in this direction.



Note!

If the largest movement is opposite from the smallest it is not a conventional softfoot and you will be asked to check the foundation.

Function buttons




	Leave Softfoot.
	See "Control panel" on page 15.
	Save. Only available when you have started Softfoot from the main menu.
	Zero value of selected foot.
	Toggle button to switch machine. To check Softfoot, distances between feet pairs are necessary. If needed, the Enter distance view is displayed. <i>Not available for E420.</i>
	Remeasure Softfoot.
	Continue to Measure view, only available when you have started Softfoot from the program Horizontal.

VERTICAL





The program Vertical is used for vertical and/or flange mounted machines.

Preparations





1. Mount the M-unit on the movable machine and the S-unit on the stationary machine.
2. Select  and  to open Vertical program.
3. Enter distances. Confirm each distance with .

If you have a barcode reader, simply scan the barcode and all machine data is read.
See “Measurement file handling” on page 11.






- 1 Distance between S-unit and M-unit.
Measure between the rods. **Mandatory**.
- 2 Distance between S-unit and centre of coupling. **Mandatory**.
- 3 Number of bolts (4, 6 or 8 bolts).
- 4 Bolt circle diameter (centre of the bolts).
- 5 Coupling diameter. Select  to activate field.


Function buttons

	Leave program.
	See “Control panel” on page 15.
	Select to enter diameter of coupling.
	Forward to measure view.

Measure


The program Vertical uses the 9-12-3 method.

1. Position the units at 9 o'clock, at bolt number one. Make sure that it is possible to also position the units at 12 and 3 o'clock.
2. Press  to register first position. The first position is automatically set to zero.
3. Turn units to position 12 o'clock.
4. Press  to register position.
5. Turn units to position 3 o'clock.
6. Press  to register position. Measurement result is displayed.




Edge warning

When the laser beam is close to the edge, the edge is “lit up” as a warning. It is not possible to register values when you see the edge warning.





Result

The result is displayed as sideways offset in the coupling and angular error between shafts.
















Live values

The values can be displayed live in two directions:

- Live in the 9-3 direction.
Select  and position the measuring units at 3 o'clock.
- Live in the 6-12 direction.
Select  and position the measuring units at 12 o'clock.



Function buttons

	Back, remeasure from first position.
	 See "Control panel" on page 15.
	Save, see "Measurement file handling" on page 11.
	Set tolerance.
	Show target. This is a quick way to see where the laser beam hits the target and how the measuring units are positioned.
	Print report on thermal printer (optional equipment). Only available when you open a saved measurement.
	Adjust distances. Press  to confirm changes. The result is recalculated.
 	Toggle button. Switch between showing live values in the direction 9-3 or 6-12.
	See "Shim result view" on page 62.
 /100	Toggle button. Switch between to show gap and show angular error per 100 mm. For this to work you need to set the coupling diameter.

Shim result view

To view this, you need to enter number of bolts and diameter of bolt circle.



1. Select  to open Shim value view. The values are not live.
2. Read values. The highest bolt is calculated as 0.00. Values below zero indicates that the bolt is low and need shimming.
3. Select  to return to Result view.

Note!

If you shim the machine, remeasure from position 9 o'clock to update all measurement values.

Adjust machine

1. Compare the offset and angular error to the tolerance demands.
2. If the angular error need to be adjusted, please shim the machine first, then adjust the offset.
3. Tighten the bolts and remeasure.




Easy-Laser® BTA system consists of a laser transmitter and a detector. Magnetic mountings on laser and detector make it easy to mount the equipment. Non-magnetic sheave/pulleys can be aligned as the units are very light and can be mounted using double-sided tape.

Note!


BTA is not included in the Shaft or Geo systems but bought as an option.



All types of sheave/pulleys can be aligned, regardless of belt type. You can compensate for sheaves of varying widths.



The misalignment can be offset or angular. It can also be a combination of both.




Preparations


- Check the sheaves for radial runout. Bent shafts will make it impossible to perform an accurate alignment.
- Check the sheaves for axial runout. If possible, adjust with the mounting screws of the bushings.
- Make sure that the sheaves are clean from grease and oil.

Mount the units


The units are mounted on a flat machined surface with magnets. The magnets are very strong, try to soften the touch by putting just one magnet to sheave first, then turning the other ones in. Non-magnetic sheave/pulleys can be aligned as the units are very light and can be mounted using double-sided tape.




1. Mount the laser transmitter on the stationary machine.
2. Mount the detector on the movable machine.
3. Make sure all magnetic surfaces are in contact with the sheave.



All of the magnetic surfaces must be in contact with the object.





Align with targets




Measure using Display unit








The XT190 can be used as a separate tool, see “Measure without Display unit” on page 68.

Enter distances

- 1. Connect to the Display unit.
- 2. Press the ON button on the laser transmitter.
- 3. Select  to open the BTA program.
- 4. Select  if you want to enter sheave face width. Press **OK**.
- 5. Enter distance between feet pairs. Press **OK**.





Function buttons

	Leave program.
	See “Control panel” on page 15.
	Sheave face width. Select to activate fields if the sheaves have different face widths.
	Contains a sub menu. The Display unit automatically recognize where the units are placed. However, you can do this manually as well.  Set M-unit to the left.  Set M-unit to the right.  Return to Automatic configuration.

Sheave face width


The distance from the belt to the axial face of the sheave can be different on the two sheaves. To calculate a possible offset the system requires both sheave face widths.

- 1. Measure the distance from the belt to the axial face of the sheave.
- 2. Select  to activate fields and enter distances.



Measure

Make sure that the laser line hits the detector aperture. The Display unit shows the offset and angular misalignment.



Function buttons

	Back. Return to enter distances.
	See “Control panel” on page 15. Save, see “Measurement file handling” on page 11. Set tolerance. See also <i>Tolerance</i> on next page. Print on thermal printer (Optional equipment). Available when you have saved the measurement.
	Edit distance.

Values – colours

White	No tolerance set.
Green	Value within tolerance.
Red	Value outside tolerance.
++++	Loss of signal, laser beam interrupted for example.


Note!

The laser transmitter flashes when the battery is low. Change the batteries before you continue to measure.

Tolerance

Recommended maximum tolerances from manufacturers of belt transmissions depends on type of belt, usually between 0.25–0.5°.

1. Select . The tolerance view is displayed.



<°	mm/m mils/inch	
0.1	1.75	
0.2	3.49	
0.3	5.24	
0.4	6.98	Recommended
0.5	8.73	
0.6	10.47	
0.7	12.22	
0.8	13.96	
0.9	15.71	
1.0	17.45	

2. Select  to set user defined tolerance.

Adjust

Start by adjusting the sheave, and then the machine.

- Correct offset by moving the movable machine with axial jackscrews, or by repositioning one of the sheaves on its shaft.
- Correct vertical angular error by shimming the movable machine.
- Correct horizontal angular error by adjusting the movable machine with lateral jackscrews.

When you adjust the machine one way, it often affects the machine's other alignment conditions. Which means this process may have to be repeated several times.


Note!


If not using the system for a long period of time, remove the batteries.

Measure without Display unit

The XT190 can be used as a separate tool.


Measure

1. Press  to start the detector and ON to start the laser transmitter.
2. Read the values. Offset, horizontal angle and vertical angle are displayed.
3. Adjust machine, see previous page.





Different sheave width

If the sheaves have different face widths, just add or subtract the difference from the zero value to get the value for perfect alignment.





Settings


Press  to open the settings view. Use  to move up and down in the menu.


- Press  to switch position on the M and S-unit.
- Toggle between mm and inch with .

Battery

Press  to see the battery status of the detector. While the battery is charging, there is a green flashing light. The laser transmitter flashes when the battery is low. Change the batteries before you continue to measure.

 Red, flashing once: Battery empty.

 Red, flashing twice: Battery needs charging.

 Green, flashing three times: Good.

 Green, fixed light: Battery full.

Note!

If not using the system for a long period of time, remove the battery from the laser transmitter.

VIBROMETER



Easy-Laser® Vibrometer is used in preventive as well as active maintenance work on rotating machinery. It measures the vibration level and bearing condition of machinery.

When measuring vibration level, Easy-Laser® Vibrometer is measuring the effective velocity (mm/s or inch/s RMS) in the frequency range between 2 and 3200 Hz. This range covers most of the frequencies that will occur for the majority of mechanical malfunctions and imperfections, for example unbalance and misalignment.

When used to measure bearing condition the Easy-Laser Vibrometer is measuring the effective acceleration (RMS) in the frequency range between 3200 and 20000 Hz. Trend analysis of the bearing condition value can be used to determine wear and tear of machine bearings.



Mount directly on machine

It is possible to remove the magnetic tip and mount the probe directly to the machine, using the M6 threaded stud.


Measuring tip


For measuring points that are hard to reach, use the measuring tip. Simply unscrew the magnetic tip and replace with the measuring tip. When measuring with the measuring tip, place it firmly against the measurement point and hold it as vertical, horizontal or axial as possible. When the measuring tip is used the frequency range is reduced to about 800 to 1500Hz.

Note!


















The Vibrometer (Part no. 12-0654) that is needed for this program has been discontinued.

Measure

1. Use the standard red cable to connect the Vibrometer directly to the Display unit.
Wireless units cannot be used.
2. Select  to open the Vibrometer program.
 - Enter rpm. Optional.
 - Use the navigation buttons if you want to register another point than is selected by default.
3. Place the vibrometer against the measurement point. Pressing more firmly should not change the reading. If this happens, adjust the measuring point.
4. Wait ten seconds for the value to stabilize.
5. Press **OK** to register value.




Function buttons

	Leave program.				
	 See "Control panel" on page 15.  Save, see "Measurement file handling" on page 11.  Print report on thermal printer (optional equipment).  Generate report. Available when you open a saved measurement.				
 	Toggle button. Show values for bearing condition or vibration level.				
	Toggle button. Show high frequency (10–3200 Hz) or low frequency (2–3200 Hz).				
	Contains a submenu <table border="1"> <tr> <td></td><td>Clear selected measurement point.</td></tr> <tr> <td></td><td>Clear all measurement points.</td></tr> </table>		Clear selected measurement point.		Clear all measurement points.
	Clear selected measurement point.				
	Clear all measurement points.				
	Tolerance. Show tolerance table for vibration level and bearing condition value.				

Vibration level

In the Display unit, a table from ISO 10816-3 standard is shown. This standard is used for machines with power above 15kW and nominal speeds between 120–15000 rpm.

1. Use navigation buttons to select a measurement point.
2. Select  to open the tolerance table. It displays the values for the selected point.



Rigid or flexible

The ISO standard is classifying the machines differently if the machines have flexible or rigid foundations. Usually this is determined from drawings and calculations of the machine.

Groups

- Group 1. Large machines with rated power above 300kW. Electrical machines with shaft height $H > 315\text{mm}$. Operating speed ranges from 120 to 15000 rpm
- Group 2. Medium-sized machines with a rated power above 15kW up to and including 300kW. Electrical machines with shaft height between $160 < H < 315\text{ mm}$. Operating speed normally above 600 rpm.
- Group 3. Pumps with multivane impeller and with separate driver with rated power above 15kW.
- Group 4. Pumps with multivane impeller and with integrated driver with rated power above 15kW.

Guideline

Another standard you can use is ISO 2372 class 4, for large machines on flexible foundations.

0 – 3 mm/s 0 – 0.12inch/s	Small vibrations. None or very small bearing wear. Low noise level.
3 – 7 mm/s 0.12 – 0.27 inch/s	Noticeable vibration levels often concentrated to some specific part as well as direction of the machine. Noticeable bearing wear. Seal problems occur in pumps etc. Increased noise level. Plan action during next regular stop. Keep the machine under observation and measure at smaller time intervals than before to detect a deterioration trend if any. Compare vibrations to other operating variables.
7 – 18 mm/s 0.27 – 0.71 inch/s	Large vibrations. Bearings running hot. Bearing wear-out cause frequent replacements. Seals wear out, leakage of all kinds evident. Cracks in weldings and concrete foundations. Screws and bolts are loosening. High noise level. Plan action soonest.
> 18 mm/s > 0.71 inch/s	Very large vibrations and high noise levels. This is detrimental to the safe operation of the machine. Stop operation if technically or economically possible considering the plant stop cost.


Bearing condition value


Bearing condition value is used for trend analysis. If the bearing condition value increases over time, it can be a sign that the bearing is poorly lubricated, overloaded due to misalignment or has a damaged surface. A high bearing condition value can however appear in gearboxes, converting machines with cutters and similar machines without any bearing fault. This is because this type of machinery naturally produces high frequency vibrations that are similar to the vibrations produced by a machine with a bearing fault.

The bearing condition value is the quadratic mean, RMS value, of all high frequency vibrations between 3200 Hz to 20000 Hz. This value is an acceleration average measured in multiples of the standard gravity constant, g.

The diagram below is only a guide to interpret the bearing condition value. A high bearing condition value should always be used as a request to make detailed frequency analysis. Do not change bearings before this is done.

Open tolerance table for bearing condition

1. Select a measurement point.
2. Select  to open the tolerance table.



TECHNICAL DATA

Part No. 12-1043, E540-A (with small case)

Part No. 12-0775, E540-B (with large case)

A complete system contains	
1	Display unit E52
1	Measuring unit ELM
1	Measuring unit ELS
1	Display unit
2	Shaft brackets with chains
2	Extension chains
1	Set of rods 4x60 mm, 4x120 mm [4.72", 2.36"]
1	Measuring tape 3 m [9.8 ft]
1	USB memory stick with EasyLink™ PC software
1	USB cable
1	Charger (100–240 V AC)
1	DC split cable for charging
1	DC to USB adapter, for charging
1	Shoulder strap for Display unit
1	Carrying case



System	
Relative humidity	10–95%
Weight (complete system)	E540-A: 6.6 kg [14.5 lbs] E540-B: 7.7 kg [17.0 lbs]
Carrying case	E540-A, WxHxD: 460x350x175 mm [18.1"x13.8"x6.9"] E540-B, WxHxD: 500x400x200 mm [19.7"x15.7"x7.9"]

Charger for E-series display unit

Part. no 03-1243

Wall socket connection cable also needed, choose part depending on country of use.

- Only the charger supplied by Easy-Laser may be used.
- Do not use a damaged charger or connection cable as it can be hazardous. A damaged charger should be replaced.



Input voltage	100-240V AC, 50/60Hz
Output voltage	12V DC, 2A
Power cords available	US, EU, UK and AUS.
Humidity	8% to 90% (storage 5% to 95%)
Operating temperature	0–40°C (storage temperature: –25°C to 70°C)
Altitude	0-2000m
Designed for indoor use only (pollution degree 2)	

Display unit E52

Part no. 12-0700

In the Display unit you are guided through the measurement procedure and can save and analyze the results.



- A Connection for charger
- B USB A
- C USB B
- D Easy-Laser® measurement equipment

Display unit	
Type of display/size	VGA 5.7" colour
Displayed resolution	0.001 mm / 0.05 thou
Internal battery (stationary)	Li-Ion, 3.7 volt, 43Wh, 11600 mAh
Operating time	Approx. 30 hours (Normal operating cycle)
Connections	USB A, USB B, Easy-Laser® units
Storage memory	>100,000 measurements
Help functions	Calculator, Converter
Housing material	PC/ABS + TPE
Dimensions	WxHxD: 250x175x63 mm [9.8x6.9x2.5"]
Weight	1020 g [2.3 lbs]
Environmental protection	IP Class 65
Operating temperature	-10–50 °C
Altitude	0-2000m
Designed for outdoor use (pollution degree 4)	
Cables	
Type	With Push/Pull connectors
System cable	Length 2 m [78.7"]
USB cable	Length 1.8 m [70.8"]
EasyLink™ data base software for PC	
Minimum requirements	Windows® XP, Vista, 7. For the export functions, Excel 2003 or newer must be installed on the PC.

Measuring units

Part no. 12-0776

Part no. 12-0777



Measuring units	
Type of detector	PSD 30 mm [1.2"]
Wireless communication	Class I wireless technology. (RF output power: max 11 dBm, frequency: 2.402 - 2.480 GHz)
Operating time	>4 h
Resolution	0.001 mm [0.05 mils]
Measuring errors	±1% +1 digit
Measurement range	Up to 10 m (33 feet)
Type of laser	Diode laser
Laser wavelength	635–670 nm
Laser class	Class 2
Laser output	<1 mW
Electronic inclinometers	0.1° resolution
Thermal sensors	- 20–60 °C
Temperature range	-10–50 °C
Housing material	Anodized aluminium / ABS plastics
Dimensions	BxHxD: 60x67x42 mm [2.36x2.63x1.65"]
Weight	164 g [5.8 oz]
Environmental protection	IP Class 65
Operating temperature	-10–50 °C
Altitude	0-2000m
Designed for outdoor use (pollution degree 4)	

See also “Charge and power the measuring units” on page 9.

BTA E180 (Optional)

Part no. 12-0796

Clean the units and the windows at the apertures with a dry cotton cloth. If not using the system for a long period of time, remove the battery from the laser transmitter.



Laser transmitter E180

Sheave diameter	> 60 mm [2.5"]
Laser class	2
Output power	<1 mW
Laser wavelength	635–670 nm
Beam angle	60°
Accuracy	Parallelity: < 0.05°, Offset < 0.2 mm [0.008"]
Battery type	1xR6 (AA) 1.5 V
Battery operation	8 hours cont.
Material	ABS plastics / Hard anodized aluminium
Dimensions BxHxD	145x86x30 mm [5.7x3.4x1.2"]
Weight	270 g [9.52 oz]
Operating temperature	-10–50 °C
Altitude	0-2000m

Designed for outdoor use (pollution degree 4)

Detector unit E180

Sheave diameter	> 60 mm [2.5"]
Displayed resolution	(Changeable between mm/inch) Axial offset: 0.1 mm [0.005"] Angular value: 0.1°
Measurement distance	Up to 3 m [9.8'] between transmitter and detector
Measurement range	Axial offset: ±3 mm [0.12"] Angular value: ±8°
Display resolution	Offset: 0.1° Angle: 0.01°
Display type	Yellow OLED 96x96 pixels
Connection	Wireless. RF output power: max 11 dBm, frequency: 2.402 - 2.480 GHz)
Battery type	Li-Ion
Battery operation	5 hours continuously
Housing material	ABS plastics / Anodized aluminium
Dimensions BxHxD	95x95x36 mm [3.7x3.7x1.4"]
Weight	190 g [6.7 oz]